


B-9

XT600 ('91) WIRING DIAGRAM



- ① C.D.I. unit
- ② Main switch
- ③ Front brake switch
- ④ Ignition coil
- ⑤ Spark plug
- ⑥ Rear brake switch
- ⑦ Sidestand switch
- ⑧ A.C. magneto generator
- ⑨ Rectifier/regulator
- ⑩ Tail/brake light
- ⑪ Rear flasher light (right)
- ⑫ Rear flasher light (left)
- ⑬ Battery
- ⑭ Fuse
- ⑮ Neutral switch
- ⑯ "ENGINE STOP" switch
- ⑰ "HORN" switch
- ⑱ "TURN" switch
- ⑲ "LIGHTS" (dimmer) switch
- ⑳ "LIGHTS" switch
- ㉑ Horn
- ㉒ Flasher relay
- ㉓ Front flasher light (left)
- ㉔ Front flasher light (right)
- ㉕ Meter light
- ㉖ "HIGH BEAM" indicator light
- ㉗ "TURN" indicator light
- ㉘ "NEUTRAL" indicator light
- ㉙ Auxiliary light
- ㉚ Headlight
- A For Germany